


APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
TAFISMAN	

Fig.1 - Simplified Diagram of Instant Musician, Recording Artist and Composer System




APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
DRAFTSMAN	

Fig.2 - Instant Musician, Recording Artist and Composer Opening Display



APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
DRAFTSMAN	

Fig. 3 - Instrument and Song Selection Display



APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
DRAFTSMAN	

Fig. 3A - Song or Instrument Selection from Internet




Fig. 4 - Instant Musician User Preferences







Fig. 5 - Instant Musician Start Playing Display



APPROVED BY DRAFTSMAN
O.G. FIG.
CLASS SUBCLASS

Fig. 5A - Instant Musician Preferences






Fig. 5B - Display Presentation for Tied Notes






Fig. 5C - Saving a Song Played



APPROVED BY DRAFTSMAN	O.G. FIG.
	CLASS SUBCLASS

Fig. 6 - Generation of Instant Musician Displays from Portable Memory Device or Internet

Readable/writable disk or other media with system software and a) music notes coded into keyboard key symbols for songs and b) sample note sounds for many musical instruments.



APPROVED	O.G. FIG.
BY	CLASS SUBCLASS
DRAFTSMAN	

Fig. 7 - Generation of Instant Musician Display






Fig. 8 - Playing Musical Notes of Selected Song by Typing



APPROVED BY DRAFTSMAN	O.G. FIG.
	CLASS/SUBCLASS

Fig. 9 - Generation of Portable Storage Devices
for Instant Musician, Recording Artist and Composer






Fig. 10 - Playing Back a Music Number Previously Played or Composed



APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
DRAFTSMAN	

Fig. 11 - Initial Recording Artist Display for Opening Files





Fig. 11A - Recording Artist Display for Playing and Modifying Music Files






Fig. 11B - Recording Artist Display with Frequency Transformation Tool






Fig. 11C - Recording Artist Display for Opening Additional Files






Fig. 11D - Recording Artist Display Showing Three Music Numbers Being Modified and Combined






Fig. 11E - Saving Files Made with the Recording Artist



APPROVED	O.G. FIG.
BY	CLASS SUBCLASS
DRAFTSMAN	

Readable/writable disk or other media with previously recorded music numbers




1210

1211

Disk or other media reader and writer


Fig. 12 - Recording Artist Key System Elements




1208

Computer

Speakers



1206



Function keys and normal; keyboard keys supporting various aspects of volume control, note blending and frequency spectrum control

1202

Computer Keyboard

User selection control of:


1. Music numbers to be mixed or music number to be altered
2. Relative volume of each mixed number
3. Alteration of each music number's frequency spectrum
4. Controls for starting, pausing and finishing music numbers recorded

1203



Mouse or other pointing device

Fig. 13 - Instant Composer Opening Display



Instant Musician, Recording Artist and Composer

File Edit Instrument/Song Preferences Start Playing Play Back Recording Artist **Composer** Window Help

Instant Composer MAIN

1320

Click either place or type!

1325

Click Here

1319

Note You Added

ABD

1318

I love it

1326

Word Typed (Click here to enter)

1316

Play Back 2 Sec

Play Back 30 Seconds

Play Back 5 Sec

Play Back 1 Minute

Play Back 10 Sec

Play Back 2 Minutes

Play Back Whole Number

Finish

1322

Composing mode: Click or type


Instrument: Piano

1323

1317


The illustration shows a vintage computer monitor displaying a software interface titled "Instant Musician, Recording Artist and Composer". The interface has a menu bar with options: File, Edit, Instrument/Song, Preferences, Start Playing, Play Back, Recording Artist, Composer, Window, and Help. Below the menu bar is a title bar that says "Instant Composer". The main workspace contains a piano keyboard at the top, a musical staff with a treble clef and 4/4 time signature, and a text input area for lyrics. A "Sound Input" arrow points to the staff, and a "Word Inputted" arrow points to the lyrics "I love it". Below the staff, a "Note Added" box shows "ABD A". The interface also includes a "Composing mode" section with a piano icon and a "Play Back" section with buttons for "Play Back 2 Sec", "Play Back 5 Sec", "Play Back 10 Sec", "Play Back 30 Seconds", "Play Back 1 Minute", "Play Back 2 Minutes", "Play Back Whole Number", and a "Finish" button. A small "MAIN" button is in the top right corner. The monitor is part of a desktop system with a keyboard and a mouse.

Fig. 13C - Instant Composer Computer Keyboard Composing Display




APPROVED O.G. FIG.
BY CLASS/SUBCLASS
DRAFTSMAN

Fig. 13D - Saving Music Composed



APPROVED	O.G. FIG.
BY	CLASS/SUBCLASS
DRAFTSMAN	

Fig. 13E - Instant Composer Display for Modification of Existing Music



U.G. FIG.
CLASS/SUBCLASS
BY
DRAFTSMAN

Fig. 14 - Instant Music Composer Key Software Elements

